

### Leaks at Filter

Items to check:

1. Defective leaking pressure gauge.
2. Plumbing leak (Call for repairs).
3. Backwash valve O-Ring damaged or missing. (Repair/replace)
4. Air bleed valve needs tightened or replaced.