

**Motor hums but will not start**

Items to check:

1. Dirty starter contacts
2. Starting capacitor bad
3. Starter winding burned out
4. Call for repairs on 1 through 3 above
5. Plugged impeller