

Air bubbles coming through cleaning heads

Items to check:

1. Leak at suction side of pump (Call for repairs.)
2. Pool water level too low
3. Skimmer weir stuck
4. Leak at pump hair and lint lid. Remove, clean "O-Ring", lid o-ring seat and pump o-ring seat. Reseal pump lid.
5. If system has an o-zone unit installed, some fine bubbles will be normal.